


Always-Displayed Items



1 Displayed screen

- MEAS** Measurement screen
(Press **MEAS** to display)
- SYSTEM** System screen
(Press **SYSTEM** to display)
- FILE** File Operations Screen
(Press **FILE** to display)

2 Displayed Page

Each page shows different screen contents: select the appropriate page as needed. Switch the page with **◀ ▶**.

3 Operating State Indicators

- WAIT** Lights up while in the integration standby state.
- RUN** Indicates integration is in progress.
- STOP** Indicates integration is stopped.
- HOLD** Indicates Data Hold is active.
- PEAK** Indicates Peak Hold is active.

4 Key-Lock Indicator

- LOCK** Lights to indicate Key Lock is active (keys are locked, after holding **ESC / On** for three seconds).
Hold **ESC / On** again for three seconds to unlock.

5 Time display

Displays the current date and time.
(To set the clock: See Chap. 6 of the instruction manual.)


6 Interface Indicators

- USB** Lights when the instrument is connected to a computer by USB cable (and the computer is on).
- LAN** Lights when the instrument is connected to a LAN.

7 Storage Media Indicators

Level indicators for the CF card and USB memory stick. The used storage space is indicated in yellow, and it turns to red when the media is 95% full. The round indicator to the left of the level meter will turn yellow-green while the media is being accessed.

Additional Capabilities



See the instruction manual for details, including setting procedures for measurement and display, convenience features and more.

PW3390 POWER ANALYZER

Measurement Guide

HIOKI

Read First



EN

Feb. 2018 Revised edition 1 Printed in Japan
PW3390A966-01 18-02H

Thank you for purchasing the HIOKI Model PW3390 Power Analyzer.
This guide introduces the Power Analyzer's basic measurement procedure to first-time users.
Before using the instrument, be sure to read the Instruction Manual carefully.

1. Connect the Cables and Sensors, and Power On

Pre-connection inspection

- Voltage measurement cables and power cord**
Does any cable insulation appear damaged, or is bare metal exposed?
- Current sensors**
Is a jaws cracked or damaged?
- PW3390**
Is damage to the instrument evident?

If damage is found.

Contact your dealer or Hioki representative if you find any damage.


Power-on confirmation

- Does the self-test (model and version) display?
- When the self-test finishes, does the **[Wiring]** page of the Setting or Measurement screen appear (according to when the instrument was last turned off)?


If the self-test does not display, or if an error is displayed.

The power cord may be damaged, or the instrument may have internal damage. Please contact your dealer or Hioki representative.


Power cord




Plug the other end of the power cord into an outlet.



3 Voltage measurement cables



4 Current sensor cables



5 Power-on



For best precision, allow at least 30 minutes warm-up before executing zero adjustment and measuring.

Operation keys

MENU keys

- Select a screen
- MEAS** key: Measurement screen
- SYSTEM** key: System screen
- FILE** key: File operation screen

PAGE keys
Changes the screen page.

FUNCTION keys (F keys)
Select and change display contents and settings.

RANGE keys

- Change the voltage (U) and current (I) measurement ranges.
- Pressing the **AUTO** key activates auto-ranging.

ENTER key

Accepts selections and changes to settings.

ESC (Escape) key

- Cancels the last change to a setting, and returns it to its previous state.
- Hold for three seconds to toggle the key lock.

CURSOR key
Move the cursors.

SHIFT key
(Lit when running)
Activates alternate key functions.

0 ADJ (Zero Adjustment) key
Performs zero adjustment and current sensor degaussing.

SAVE key
Saves data to the storage media.
Press **SAVE** key after pressing the **SHIFT** key to capture a screen image to the storage media. (Screen capture)

HOLD key
Toggles the Hold and Peak Hold function.

DATA RESET key
Resets the integration values.

START/STOP key
Starts and stops integration and saving operations.


Select the Wiring Mode

1 Press **SYSTEM** to display the System screen, and select the **[Wiring]** page with the **◀ ▶** keys.

2 Press **F1 [Select]**.

3 Use the **◂ ◃** keys to select the wiring mode (phase configuration) of the measurement system.

4 Press **F1** to accept the selection. The wiring diagram(s) are displayed.



Select the Current Sensors


If using the CT9920 Conversion Cable, set the models of the current sensors.
If not using the CT9920, there is no need to set the models of the current sensors as that information will be automatically detected.

1 Press **SYSTEM** to display the System screen, and select the **[Sensor]** page with the **◀ ▶** keys.

2 Select the channel whose current sensor you wish to configure with **◂ ◃**.

3 Select the sensor with the **F** key.

4 To increase measurement precision, configure phase correction for the current sensors. See: Instruction manual Sec. 3.10





Attach voltage measurement cables and current sensors to the measurement lines according to the wiring diagram(s).

<IMPORTANT> After 30 minutes warm-up, always perform zero adjustment before attaching to the lines.

1. Press **MEAS** to display the Measurement screen.

2. Press **0 ADJ.**
[Execute Zero Adjust.] is displayed.

3. Press **ENTER**.
[Executing Please wait... All keys are disabled now.] is displayed for 30 seconds, until finished.



5. Execute quick setup, and verify correct wiring


1 Press **F6 [Easy Set]**, and then **ENTER** to execute.

When execute quick setup

Executing quick setup automatically configures the following settings to the Hioki-recommended values for the selected wiring mode (phase system): voltage and current ranges, sync source, lower measurement frequency limit, integration mode, harmonic sync source and rectification method.

2 Verify that appropriate measurement values are displayed.

3 Verify that the vectors are displayed with the appropriate range, and that vectors are not too short, or of unequal lengths.



6. View Measurement Values

Press **MEAS** to display the Measurement screen, and press **◀ ▶** to switch screen pages.

Wave + Noise



This page displays waveforms and noise of voltage and current. Both data can be saved.

XY Graph




This page displays an X-Y graph of measurement parameters selected for horizontal and vertical axes.

Vector




This page displays measured harmonic voltage, harmonic current, and harmonic power on channels 1 to 4 as numerical values and as vectors.

Select



This page displays the parameters which you are selected.

Trend




This page displays fluctuations of up to eight measured values.

CH1 to CH4




This page displays measured power, voltage and current values, integration values, and provides access to harmonic graphs and lists for each channel.

Efficiency



This page displays the numerical values of efficiency and loss determined by calculation formulas.

Motor



This page displays measured values for the motor analysis function.

Displayed only on the PW3390-03 (model with motor analysis and D/A output).