


V101



V101

10A SPST Enclosed Relay With HOA Switch

Installer's Specifications

Operating Temperature	-40 to 55 °C (-40 to 131 °F)
Operating Humidity	10 to 90% RH, non-condensing
Expected Relay Life	Electrical (@ rated current) 100,000 cycles; Mechanical (unpowered) 10,000,000 cycles
Relay Status	LED ON = Energized
Wire Specifications:	
Lead Length	14" (356 mm) min.
Gauge	UL1015; Coil: 18 AWG; Contacts: 16 AWG
Insulation Class	600 VAC RMS
Agency Approvals	UL508 enclosed device listing, Pollution Degree 2

Installation

Disconnect and lock out all power sources before beginning the installation.

- Using the threaded nipple, connect the relay to the desired enclosure through a knock out hole.
- Secure with the conduit nut provided.
- Connect coil wires:
 - Choose the coil common lead (white with yellow stripe) and connect it to the common (-) source termination point.
 - Choose either the low voltage (10-30VAC/DC, white with blue stripe) or high voltage (120VAC, white with black stripe) lead, depending on the application requirements, and connect it to the (+) source termination point.*
- Connect relay contacts:
 - Choose the two orange wires (N.O. contact) and connect to the switched load.
- Secure the enclosure and reconnect power.

* Isolate or insulate all non-terminated wires according to local electrical code requirements, i.e. wire nut.

⚡ ⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH


- Follow safe electrical work practices. See NFPA 70E in the USA, or applicable local codes.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Read, understand and follow the instructions before installing this product.
- Turn off all power supplying equipment before working on or inside the equipment.
- Use a properly rated voltage sensing device to confirm power is off. DO NOT DEPEND ON THIS PRODUCT FOR VOLTAGE INDICATION

Failure to follow these instructions will result in death or serious injury.


NOTICE

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- The installer is responsible for conformance to all applicable codes.
- Mount this product inside a suitable fire and electrical enclosure.

Dimensions




Wiring Color Codes



Wiring Example

Nipple mount directly to a panel




Contact and Coil Specifications


TYPICAL COIL PERFORMANCE			
Pull-in Voltage	AC	DC	
	10-30V.....	8	10
	120V.....	58	
Drop-out Voltage	AC	DC	
	10-30V.....	3	4
	120V.....	22	
Voltage	Coil Current		
		AC	DC
10V.....	57mA	32mA	
12V.....	70mA	40mA	
24V.....	93mA	53mA	
30V.....	100mA	55mA	
120V.....	63mA	-	

CONTACT RATINGS	
SPDT Resistive.....	28VDC, 10A, N.O. 28VDC, 5A, N.C.
Motor.....	120VAC, 1/3HP, N.O. only

Nipple mount to a 2x or 4x electrical box



HOA Positions



- HAND** Up position: contacts are closed.
- OFF** Middle position: contacts are open.
- AUTO** Down position: control system actuates the contacts.