

© 2006 The Authors
Journal compilation © 2006 Blackwell Publishing Ltd




Communication with the connected transmitter is established automatically, without any problems to match the PC communication port to the software.

- USB communication
- Automatic matching of communication ports
- Automatic transmitter identification for quick start up
- Diagnostic LED's on the USB Interface show the communication status
- Simple installation of configuration software and drivers for the USB Interface
- User Instructions and Installation Guide included (on USB memory stick)
- Free download of configuration software, Consoft, and USB Interface software from our website

Specifications:


[illegible]

Connection cables



PC to USB
Interface


Part No:
70KAB49817



USB Interface to
IPAQ C/R 201
MiniIPAQ-HLP/-L
IPAQ C/R 330
IPAQ C/R 520 & C/R 530 HART

Part No:
70KAB49717

USB Interface



Ordering information

ICON Complete Configuration Kit	70CFGUS101
Separate parts	See above