

---

## ADT686/673Commands set

### 1 Commands instruction

(1) each command includes two parts: **mnemonic** and **parameter**. The **mnemonic** and **parameter** are separated by a space;

For example pressure:filter 0|1, <numeric>[,<numeric>], 0|1 refers to the parameter description specific optional option, <numeric> is the parameter to be input, [,<numeric>] refers to the additional parameter when the parameter is set to 1. if set the pressure filter function by this command, enter pressure:filter 1, 50,5

(2) about the parameter

Each parameter in the instruction set is marked with  $\langle \rangle$  (do not enter angle brackets when converting to actual instructions) and separated by commas.

(3) terminator

The scpi command must include a command terminator, which can be one of the follows (excluding double quotation marks): "\r\n", "\r", "\n" or "\0".

### 1.1 IEEE 488.2 common commands

| No | Commands | Description   | Parameter | Returned value                         |
|----|----------|---|-----------|--|
| 1  | *cls     | Clear the following registers:<br>Standard event register;<br>Query event register;<br>Operation event register;<br>Status byte register;<br>Error queue. | -         | -                                      |
| 2  | *idn?    | Instrument identification query, return 2 parts of data:<br>A. Product serial number;<br>B. Software version;   | -         | Product serial number,software version |
| 3  | *rst     | Program reset   | -         | -                                      |

### 1.2 Pressure commands

| No | Commands                         | Description                 | Parameter                               | Returned value   |
|----|----------------------------------|-----------------------------|---|--|
| 1. | Pressure? [all]                  | Read current pressure value | Option all: reading barometric pressure | Pressure value, pressure unit, pressure type[barometric pressure, barometric unit, barometric pressure type] |
| 2. | Pressure:unit?                   | Read current pressure unit  | None                                    | Unit name  |
| 3. | Pressure:unit<numeric> <unquost> | Set current pressure unit   | Unit id or unquoted unit name           | None   |
| 4. | Pressure:ptype?                  | Read current pressure type  | None                                    | G: gauge pressure<br>A: absolute pressure<br>D: differential pressure  |

|     |   |  |  |  |
|-----|---|--|--|--|
| 5.  | Pressure:ptypeg a d                       | Set current pressure type              | G: gauge pressure<br>A: absolute pressure<br>D: differential pressure  | None   |
| 6.  | Pressure:online?                          | Whether the pressure module is online? | None   | 0: offline<br>1: online  |
| 7.  | Pressure:range? [<unquostr>]              | Read pressure module's range           | None, 0 or 1   | None or 0: lower limit, upper limit, unit id, pressure type(g/a/d);<br>1: lower limit, upper limit, unit name, pressure type(g/a/d)            |
| 8.  | Pressure:zero                             | Pressure module zero                   | None   | None   |
| 9.  | Pressure:resolution?                      | Read pressure resolution               | None   | 4 5 6  |
| 10. | Pressure:resolution<numeric>              | Set pressure resolution                | 4 5 6  | None   |
| 11. | Pressure:filter:enable?                   | Read filter status                     | None   | 0: disable<br>1: enable  |
| 12. | Pressure:filter:enable0 1                 | Set filter type                        | 0: disable<br>1: enable  | None   |
| 13. | Pressure:filter?                          | Read filter parameter                  | None   | Two returns format:<br>First-order filter: 0, first-order filter coefficient<br>Average filter: 1, de-extreme value pairs, filter window size. |
| 14. | pressure:filter 0 1,<numeric>[,<numeric>] | Set filter type                        | Two returns format:<br>First-order filter: 0, first-order filter coefficient<br>Average filter: 1, de-extreme value pairs, filter window size. | None   |

|     |  |   |  |  |
|-----|--|---|--|--|
| 15. | Pressure:stable?                             | Read pressure stable status   | None                                   | 0: not stable<br>1: stable   |
| 16. | Pressure:stable:enable?                      | Read the status of the stable time                                  | None                                   | 0: disable<br>1: enable  |
| 17. | Pressure:stable:enable0 1                    | Set the status of the stable time                                   | 0: disable<br>1: enable                | None   |
| 18. | Pressure:stable:configure?                   | Read pressure stable status parameter                               | None                                   | Separated by comma:<br>Stability, stable time                                    |
| 19. | Pressure:stable:configure<numeric>,<numeric> | Set pressure stable status parameter                                | Stability(0.005-1), stable time(1-60s) | None   |
| 20. | Pressure:peak:enable?                        | Read pressure peak status   | None                                   | 0: disable<br>1: enable  |
| 21. | Pressure:peak:enable0 1                      | Set pressure peak status  | 0: disable<br>1: enable                | None   |
| 22. | Pressure:tare:enable?                        | Read pressure tare function status                                  | None                                   | 0: disable<br>1: enable  |
| 23. | Pressure:tare:enable0 1                      | Set pressure tare function status                                   | 0: disable<br>1: enable                | None   |
| 24. | Pressure:tare:configure?                     | Read pressure tare value  | None                                   | Pressure tare value  |
| 25. | Pressure:tare:configure<numeric>             | Set pressure tare value   | Tare value                             | None   |
| 26. | Pressure:clrdangp                            | Clear overpressure record   | None                                   | None   |
| 27. | Pressure:dangp?                              | Read overpressure record  | None                                   | Overpressure record  |
| 28. | Atm? [all]                                   | Read barometric pressure value all and read process treatment value | None                                   | Final barometric value<br>All with the original value, linear value, tare value, |

|     |          |                       |      |   |
|-----|----------|-----------------------|------|---|
|     |          |                       |      | filter value and final value. (with pressure type when switch pressure is supported)  |
| 29. | Measure? | Read the measure data | None | Type 1+ pressure value+ pressure unit id+ pressure type+ type 2+ barometric pressure+ barometric unit id+ type 3+ temperature+ temperature unit id+ type 4+ electric measurement+ electric measurement id |

### 1.3 Electric measure commands

| No | Commands                                  | Description                 | Parameter                                      | Returned value  |
|----|---|-----------------------------|--|---|
| 1. | Electricity:measure? [cal]                | Read current measured value | None or cal                                    | 1. none<br>Item no,measuredvalue,unit name<br>2. cal<br>Item no,final measured value,unitname,single-point fixed value,multi-point fixed value,linar fixed value,origin value<br>Note:<br>Item no:<br>1. current 2. voltage 3. switch 4. hart |
| 2. | Electricity:function?                     | Read current measured item  | None   | Item no[, item description]<br>Item no:<br>1. current 2. voltage 3. switch 4. hart<br>Switch:<br>0.mechanical switch 1.npn switch 2.pnp switch  |
| 3. | Electricity:function<numeric>[,<numeric>] | Set current measured item   | Item no:<br>1. current 2. voltage 3. switch 4. | None  |

|     |  |                              |   |   |
|-----|--|------------------------------|---|---|
|     |  |                              | hart<br>Switch:<br>0.mechanical switch 1.npn switch<br>2.pnp switch   |   |
| 4.  | Electricity:24venable?                       | Read 24v status              | None  | 0: disable<br>1: enable   |
| 5.  | Electricity:24venable 0 1                    | Set 24v status               | 0: disable<br>1: enable   | None  |
| 6.  | Electricity:zero                             | Electric measure zero        | None  | None  |
| 7.  | Electricity:czero                            | Electric measure cancel zero | None  | None  |
| 8.  | Electricity:switch:actions?                  | Read switch test act value   | None  | Separated by space:<br>Act valueunit name   |
| 9.  | Electricity:filter:enable?                   | Read filter status           | None  | 0: disable<br>1: enable   |
| 10. | Electricity:filter:enable 0 1                | Set filter status            | 0: disable<br>1: enable   | None  |
| 11. | Electricity:filter?                          | Read filter parameter        | None  | First-order filter: 0, first-order filter coefficient<br>Average filter: 1, de-extreme value pairs, filter window size. |
| 12. | Electricity:filter 0 1,<numeric>[,<numeric>] | Set filter parameter         | First-order filter: 0, first-order filter coefficient<br>Average filter: 1, de-extreme value pairs, filter window size. | None  |
| 13. | Electricity:scale:enable?                    | Read scaling status          | None  | 0: disable<br>1: enable   |

|     |   |                              |  |  |
|-----|---|------------------------------|--|--|
| 14. | Electricity:scale:enable 0 1  | Set scaling status           | 0: disable<br>1: enable  | None   |
| 15. | Electricity:scale?  | Read scaling configuration   | None   | Transfer function: 0:linear 1 square root<br>Input range<br>Output range<br>Decimal digits of output range |
| 16. | Electricity:scale<br>0 1 2,<numeric>,<numeric>,<numeric>,<numeric>,<unquostr>,<numeric> | Set scaling configuration    | Transfer function, input lower limit,<br>input upper limit, output lower limit,<br>output upper limit, output units,<br>decimal digits of output range | None   |
| 17. | Electricity:minmax:enable?  | Read min/max function status | None   | 0: disable<br>1: enable  |
| 18. | Electricity:minmax:enable 0 1   | Set min/max function status  | 0: disable<br>1: enable  | None   |

#### 1.4 System commands

| No | Commands   | Description                        | Parameter   | Returned value  |
|----|--|------------------------------------|---|---|
| 1. | System:error?  | Read the execute error information | None  | A message at the stack top of the error   |
| 2. | System:lock?   | Read the screen lock status        | None  | 0= unlock<br>1= lock  |
| 3. | System:lock0 1 on off  | Set the screen lock status         | 0= unlock<br>1= lock  | None  |
| 4. | System:version?<br>[\"application\"]\["os:firmware"]\["os:hardware"]<br>  \["wifi:firmware"]\["bt:firmware"]\["hart:dd"] | Read the device version            | "application" = host version,<br>"os:firmware" system firmware<br>version,<br>"os:hardware" system hardware | Default:<br>No parameter= return host version<br>With parameter= return corresponding version |

|     |  |                                 |  |   |
|-----|--|---------------------------------|--|---|
|     |  |                                 | version,<br>"wifi:firmware" wifi version<br>"bt:firmware" bluetooth version<br>"hart:dd" hartdd file version |   |
| 5.  | System:date?                             | Read system date                | None   | Date (yyyy,mm,dd)   |
| 6.  | System:date<numeric>,<numeric>,<numeric> | Set system date                 | Year, month, day   | None  |
| 7.  | System:time?                             | Read system time                | None   | Time (hh,mm,ss)   |
| 8.  | System:time<numeric>,<numeric>,<numeric> | Set system time                 | Hour, minute, second   | None  |
| 9.  | System:time:format?                      | Read system time format         | None   | Two values, separated by comma,<br>24/12 hours<br>Current time zone |
| 10. | System:time:format<boolean>,<numeric>    | Set system time format          | Two parameters, separated by<br>comma,<br>24/12 hours<br>Current utc time zone                               | None  |
| 11. | System:tbeep?                            | Read the touch beep status      | None   | 0 disable<br>1 enable   |
| 12. | System:tbeep<boolean> on off             | Set the touch beep status       | 0 off disable<br>1 on enable   | None  |
| 13. | System:pbeep?                            | Read the prompt beep status     | None   | 0 disable<br>1 enable   |
| 14. | System:pbeep<boolean> on off             | Set the prompt beep status      | 0 off disable<br>1 on enable   | None  |
| 15. | System:orbeep?                           | Read the over range beep status | None   | 0 disable<br>1 enable   |



|     |   |   |   |                       |
|-----|---|---|---|-----------------------|
| 16. | System:orbeep<boolean> on off                     | Set the over range beep status                        | 0 off disable<br>1 on enable  | None                  |
| 17. | System:stbeep?                                    | Read the stable beep status                           | None  | 0 disable<br>1 enable |
| 18. | System:stbeep<boolean> on off                     | Set the stable beep status                            | 0 off disable<br>1 on enable  | None                  |
| 19. | System:shbeep?                                    | Read the snapshot beep status                         | None  | 0 disable<br>1 enable |
| 20. | System:shbeep<boolean> on off                     | Set the snapshot beep status                          | 0 off disable<br>1 on enable  | None                  |
| 21. | System:volume?                                    | Read system volume percentage                         | None  | Volume percentage     |
| 22. | System:volume<numeric>                            | Set system volume                                     | Volume percentage   | None                  |
| 23. | System:language?                                  | Read current language                                 | None  | Current language      |
| 24. | System:language<unquostr>[.<boolean>]             | Set current language                                  | Parameter: language zh-cn<br>Optional: restart or not, restart by default | None                  |
| 25. | System:language:config?                           | Read the list of supported languages                  | None  | Lamguage list         |
| 26. | System:language:config<quotestr>                  | Set the list of supported languages                   | Language list, separated by comma   | None                  |
| 27. | System:brightness? Percentage value               | Read the screen brightness                            | Percentage or value   | Screen brightness     |
| 28. | System:brightnesspercentage value,<numeric><br>c> | Set the screen brightness<br>Range:<br>Value 200-4096 | 1: percentage or value<br>2: brightness                                   | None                  |

|     |  |  |  |  |
|-----|--|--|--|--|
|     |  | Percentage 0-100<br>When the set value is greater than 4096 or 100%, it will be set to the greatest brightness, when the set value is lower than 200 or 0%, it will be set to the lowest brightness. |  |  |
| 29. | System:battery:online?                             | Read the battery online status   | None   | 1 : battery online<br>0 : battery offline  |
| 30. | System:battery:status?                             | Read the battery status  | None   | 0: battery communication abnormal<br>1: battery communication ok   |
| 31. | System:battery:infomation?                         | Read the current battery level, voltage, current   | None   | Current battery level, total level (mah), voltage (v), current (>0 indicates charging, <0 indicates discharging) |
| 32. | Display:acloud:captcha<br>0 1,<unquostr>,<numeric> | Show or close acload service verify code   | 1:<br>0-close the verify code, 1-show the verify code<br>2: string, verify code text<br>3: number, time-out time | None   |
| 33. | System:ble<boolean> on off                         | Bluetooth on/off   | 1 or on: on<br>0 or off: off   | No return  |
| 34. | System:ble:status?                                 | Read bluetooth status  | None   | 0: unkown;<br>1: booted;<br>2: initialized<br>3: sleep<br>4: broadcasting  |

|     |                             |                            |   |                   |
|-----|-----------------------------|----------------------------|---|-------------------|
|     |                             |                            |   | 5: connected      |
| 35. | System:ble:info? <unquostr> | Read bluetooth information | Name: return bluetooth version information<br>Mac: return bluetooth mac address<br>Version: return bluetooth firmware version | See the parameter |

### 1.5 Data management commands

| No | Commands  | Description                   | Parameter  | Returned value |
|----|---|-------------------------------|--|----------------|
| 1. | Datamanager:count?<br>Leaktest snapshot datalogger psvtest                    | Read data amount              | Leaktest: leak test<br>Snapshot: snapshot<br>Datalogger: data log<br>Psvtest: psv test   | Data amount    |
| 2. | Datamanager:info?<br>Leaktest snapshot datalogger psvtest,<numeric>,<numeric> | Read data related information | 1: leaktest: leak test<br>Snapshot: snapshot<br>Datalogger: data log<br>Psvtest: psv test<br>2: start, start point<br>3: count, length                       | Information    |
| 3. | Datamanager:delleaktest snapshot datalogger psvtest,<unquostr>                | Delete test result            | 1: leaktest: leak test<br>Snapshot: snapshot<br>Datalogger: data log<br>Psvtest: psv test<br>2: the file path that perform the deletion (without quote mark) | None           |
| 4. | Datamanager:length?<br>Leaktest snapshot datalogger psvtest,data im           | Read data length              | 1: leaktest: leak test<br>Snapshot: snapshot   | Data length    |

|    |   |                                  |   |               |
|----|---|----------------------------------|---|---------------|
|    | age,<unquostr>  |                                  | Datalogger: data log<br>Psvtest: psv test<br>2: read data file or image<br>File name (without quote mark) |               |
| 5. | Datamanager:data?<br>Leaktest[snapshot[datalogger]psvtest,data]im<br>age,<unquostr>,<numeric>,<numeric> | Read data in designated location | File name (without quote mark),<br>start point, read data length  | String format |

### 1.6 calibration commands

| No | Commands   | Description                                    | Parameter  | Returned value  |
|----|--|--|--|---|
| 1. | Calibration:electricity:data<br>123456,<numeric>,<numeric>,<quotes<br>tr>,<quotestr>,<numeric>,<numeric>,<<br>numeric> | Write electric calibration data                | 1: 0-linar<br>1-multi-point<br>2: 0-ma measure<br>1-30v measure<br>Calibration point (quoted string,<br>separated by comma)<br>Stardard point (quoted string,<br>separated by comma)<br>Year, month, day | None  |
| 2. | Calibration:electricity:data?<br>123456,<numeric>,<numeric>  | Write electric calibration value               | 1: 0-linar<br>1-multi-point<br>2: 0-ma measure<br>1-30v measure  | Multi-point: calibration point list, actual value list,<br>year, month, day<br>Single point: offset value, year, month, day |
| 3. | Calibration:electricity:ereset<br>123456,<numeric>,<numeric>   | Reset electric multi-point calibration<br>data | 1: 0-linar<br>1-multi-point<br>2: 0-ma measure   | None  |

|    |  |  | 1-30v measure   |   |
|----|--|--|---|---|
| 4. | Calibration:barosensor:data?<br>123456,<numeric>   | Read barometric sensor calibration data  | 0-two points<br>1-offset<br>2-demarcate   | With calibration data: standard value 1, measure value 1, standard value 2, measure value 2, year, month, day<br>Without calibration data: no data! |
| 5. | Calibration:barosensor:data<br>123456,<numeric>,<quotestr>,<quotes tr>,<numeric>,<numeric>,<numeric> | Write barometric sensor calibration data | 1: 0-two points<br>1-offset<br>2-demarcate<br>2: standard value(quoted string, separated by comma)<br>3: measure value(quoted string, separated by comma)<br>Year, month, day | None  |
| 6. | Calibration:barosensor:preset<br>123456,<numeric>  | Reset barometric sensor calibration data | 0- Multi-point (reset both two-point and single-point calibration data)<br>1- Single-point ( reset both two-point and single-point calibration data)                          | None  |

### 1.7 HART

| No | Commands         | Description                | Parameter | Returned value   |
|----|------------------|----------------------------|-----------|--|
| 1. | Hart:supplymode? | Read the power supply mode |           | 0-ipir internal power and internal resistance;<br>1-eper external power and external resistance; |

|    |  |                            |   |  |
|----|--|----------------------------|---|--|
|    |  |                            |   | 2-epir external power and internal resistance;<br>3-iper internal power and external resistance  |
| 2. | Hart:supplymode ipir eper epir iper 0 1 2 3        | Set the power supply mode  | 0-ipir internal power and internal resistance;<br>1-eper external power and external resistance;<br>2-epir external power and internal resistance;<br>3-iper internal power and external resistance | -  |
| 3. | Hart:searchstart stop zero[,<numeric>][,<numeric>] | Hart search;               | Start: start searching;<br>Stop: stop searching;<br>Zero: search only zero<br>Note: the start and stop can be added later in the address range parameter, such as",0,15"                            | -  |
| 4. | Hart:devices?                                      | Search device              | -   | List of devices searched (address and device type)   |
| 5. | Hart:connect<address>                              | Connect to searched device | Address   | -  |
| 6. | Hart:ondevice:process?                             | Get process option         | -   | Pv: process variable;<br>Ao: analog current;<br>%: scale percentage;<br>Sv: second viriable;<br>Tv: third viriable;<br>Fv: fourth viriable;<br>Loopcurrent: loop current |

|     |  |                              |   |   |
|-----|--|------------------------------|---|---|
| 7.  | Hart:ondevice:process:value?<br>[pv ao sv tv fv loopcurrent] | Get process value            | Pv: process variable;<br>Ao: analog current;<br>%: scale percentage;<br>Sv: second viriabile;<br>Tv: third viriabile;<br>Fv: fourth viriabile;<br>Loopcurrent: loop current | Null: current variable<br>Or designated value   |
| 8.  | Hart:ondevice:processpv ao sv tv fv loopcurrent              | Switch process value         | Pv: process variable;<br>Ao: analog current;<br>%: scale percentage;<br>Sv: second viriabile;<br>Tv: third viriabile;<br>Fv: fourth viriabile;<br>Loopcurrent: loop current | -   |
| 9.  | Hart:ondevice:parameter? <name>                              | Read the parameter           | Name: parameter name (quoted string)  | Corresponding value   |
| 10. | Hart:ondevice:parameter<name>,<"value">                      | Set the parameter            | Name: parameter name (quoted string)<br>Value: value (quoted string)  | -   |
| 11. | Hart:ondevice:info?  | Read hart device information | None or <parameter name><br>Name list:<br>Tag<br>Manufacturer<br>Devicetype<br>Deviceid<br>Writeprotect<br>Date   | Return all parameter values of the device when there are no parameters;<br>Return the corresponding parameter value for designated parameter name |

|     |                          |  |  |  |
|-----|--------------------------|--|--|--|
|     |                          |  | Message<br>Descriptor<br>Finalassemble<br>Preambles<br>Universalrev<br>Hardwarerev<br>Softwarerev<br>Devicerev |  |
| 12. | Hart:ondevice:sensor?    | Return all parameter values for the sensor or return the corresponding values based on the name of the designated parameters | None or <parameter name><br>Name list:<br>Sn<br>Unit<br>Lrl<br>Url<br>Minspan                                  | Return all parameter values of the sensor when there are no parameters;<br>Return the corresponding parameter value for designated parameter name      |
| 13. | Hart:ondevice:output?    | Return all parameter values of hart output or return the corresponding values based on the name of the designated parameters | None or <parameter name><br>Name list:<br>Unit<br>Lrv<br>Urv<br>Damping<br>Transferfunction                    | Return all parameter values of the hart output when there are no parameters;<br>Return the corresponding parameter value for designated parameter name |
| 14. | Hart:ondevice:connected? | Get the hart device connect condition  | None   | 1 value<br>1=connected, 0=unconnected  |



**Appendix 1:scpiunit id list**

| Unit id | Unit               |
|---------|--------------------|
| 2000    | Text unit          |
| 32767   | Blank unit         |
|         |                    |
| 1211    | Ma                 |
| 1212    | Ma                 |
| 1209    | A                  |
| 1240    | V                  |
| 1241    | Mv                 |
| 1281    | $\Omega$           |
| 1284    | K $\omega$         |
| 1283    | M $\omega$         |
| 1000    | K                  |
| 1001    | $^{\circ}\text{C}$ |
| 1002    | $^{\circ}\text{F}$ |
| 1003    | $^{\circ}\text{r}$ |

|      |      |
|------|------|
| 999  | °re  |
| 1005 | °    |
| 1342 | %    |
|      |      |
| 1133 | Kpa  |
| 1130 | Pa   |
| 1131 | Gpa  |
| 1132 | Mpa  |
| 1134 | Mpa  |
| 1135 | Mpa  |
| 1136 | Hpa  |
| 1137 | Bar  |
| 1138 | Mbar |
| 1139 | Torr |
| 1140 | Atm  |
| 1141 | Psi  |

|      |                     |
|------|---------------------|
| 1142 | Psia                |
| 1143 | Psig                |
| 1144 | Gf/cm <sup>2</sup>  |
| 1145 | Kgf/cm <sup>2</sup> |
| 1147 | Inh2o@4°c           |
| 1148 | Inh2o@68°f          |
| 1150 | Mmh2o@4°c           |
| 1151 | Mmh2o@20°c          |
| 1153 | Fth2o@4°c           |
| 1154 | Fth2o@68°f          |
| 1156 | Inhg@0°c            |
| 1158 | Mmhg@0°c            |
| 2001 | Mtorr               |
| 2002 | Lb/ft <sup>2</sup>  |
| 2003 | Tsi                 |
| 2004 | Psf                 |

---

|      |                    |
|------|--------------------|
| 2005 | Inh2o@60°f         |
| 2006 | Fth2o@60°f         |
| 2007 | Cmh2o@4°c          |
| 2008 | Mh2o@4°c           |
| 2009 | Cmhg@0°c           |
| 2010 | Mhg@0°c            |
| 2011 | Kgf/m <sup>2</sup> |

**Appendix 2: error definition**

| No                     | Error code | Error description          | Definition  |
|------------------------|------------|----------------------------|---|
|                        | 0          | No error                   | No error  |
| <b>Command error</b>   |            |                            |   |
| 2                      | 120        | Commandparameter error     | Command parameter error   |
| 3                      | -108       | Parameter not allowed      | Too many parameters, or the command without parameters contains parameters    |
| 4                      | -109       | Missing parameter          | Parameter missed  |
| 5                      | -110       | Command header error       | Command header error  |
| 6                      | -114       | Header suffix out of range | Command header suffix is out of range   |
| 7                      | -123       | Numeric overflow           | Number overflow, the absolute value of the number exponent is greater than 43 |
| 8                      | -151       | Invalid string data        | Invalid string, such as mismatched quotes                                     |
| 9                      | -171       | Invalid expression         | Invalid expressions, such as mismatched parentheses                           |
| <b>Execution error</b> |            |                            |   |
| 10                     | -200       | Execution error            | Execution error   |
| 11                     | -221       | Settings conflict          | Settings conflict   |
| 12                     | -222       | Data out of range          | Parameter out of the command's range  |
| 13                     | -223       | Too much data              | Too much data beyond processing capacity                                      |
| 14                     | -224       | Illegal parameter value    | Illegal parameter value   |
| 15                     | -230       | Data corrupt or stale      | Invalid data, or the data is being read, and no valid data has been obtained  |
| 16                     | -240       | Hardware error             | Hardware error  |
| 17                     | -256       | File name not found        | File name not found   |
| 18                     | -282       | Illegal program name       | Illegal program name  |
| 19                     | 220        | Measure error              | Measure error   |

| No | Error code | Error description                  | Definition  |
|----|------------|------------------------------------|---|
| 20 | 221        | Failed to set measure function     | Failed to set measure function  |
| 21 | 222        | Failed to read measure value       | Failed to read measure value  |
| 22 | 223        |                                    |   |
| 23 | 224        |                                    |   |
| 24 | 240        | Control error                      | Control error   |
| 25 | 241        |                                    |   |
| 26 | 242        |                                    |   |
| 27 | 243        |                                    |   |
| 28 | 260        | Calibration error                  | Calibration error   |
| 29 | 261        | Calibration secured                | Calibration secured, can not perform calibration  |
| 30 | 262        | Invalid calibration secure code    | Invalid calibration secure code   |
| 31 | 263        | Missing calibration value          | During current/voltage calibration, this error will occur if the calibration value is set without setting the calibration point |
| 32 | 264        | Missing calibration data           | This error occurs when the calibration point is set continuously, but the calibration value is not set                          |
| 33 | 265        | Failed to set calibration function | Failed to set calibration function  |
| 34 | 266        | Calibration data is not enough     | When saving the calibration data, if the calibration data does not reach 3 points, this error will occur                        |
| 35 | 271        | Setion_name_not_found              | Setion name not found   |
| 36 | 272        | Key_name_not_found                 | Key name not found  |
| 37 | 291        | Update secured                     | Update secured  |
| 38 | 292        | Invalid update secure code         | Invalid update secure code  |
| 39 | 293        | Not found the service pack         | Not found the service pack  |
| 40 | 294        | The service pack unavailable       | The service pack unavailable  |

| No                          | Error code | Error description                             | Definition                                    |
|-----------------------------|------------|---|---|
| 41                          | 295        | Appupdate not found                           | Appupdate.exe not found                       |
| <b>Device related error</b> |            |   |   |
| 42                          | -310       | System error                                  | System error                                  |
| 43                          | -311       | Memory error                                  | Memory error                                  |
| 44                          | -350       | Queue overflow                                | Queue overflow                                |
| 45                          | -360       | Communication error                           | Communication error                           |
| 46                          | 301        | Internal module is not connected              | Internal module is not connected              |
| 47                          | 302        | External module is not connected              | External module is not connected              |
| 48                          | 303        | Supply module is not connected                | Supply module is not connected                |
| 49                          | 304        | Vacuum module is not connected                | Vacuum module is not connected                |
| 50                          | 361        | Open wlan failed                              | Open wlan failed                              |
| 51                          | 362        | Set wlan address mode failed                  | Set wlan address mode failed                  |
| 52                          | 363        | Set wlan address failed                       | Set wlan address failed                       |
| 53                          | 364        | Communication port to wifi module is not open | Communication port to wifi module is not open |
| 54                          | 365        | Wlanisnotconnected                            | Wlan is not connected                         |